

- 1.Use an open-end wrench to remove the 4 bolts. Line up the holes with the holes on the mounting plate of the footrest. Note: leave the bolts loose until all 4 have been installed, then tighten them down.
- 2.Once the footrest is installed, take the chair top and set it on top of the pump shaft and lining up the SLOT with PIN. Note: the SLOT should be facing toward the FRONT of the chair.
- 3.Sit in the chair and gently bounce up and down in order to connect the chair top to the pump shaft. Note: when moving the chair, LOCK THE PUMP PEDAL. Grab the pump pedal and use a strong hand-hold when moving the chair.